



SCENTROID SM100

IN-FIELD ODOUR MEASUREMENT

Scentroid SM100 is the world's only in-field odour measuring device that allows users to accurately quantify ambient odour strength in OU/m³. This revolutionary device offers an easy-to-use and cost effective alternative to guessing at odour strength or using expensive odour measuring laboratories.

► CAPABILITIES

The SM100 can conduct odour measurements from:

- Ambient air without any additional sampling equipment
- Directly from smoke stacks or filter inlets
- Flux chamber
- Air samples stored in PTFE/Tedlar bags

Use the SM100 to:

- Conduct daily odour emission assessment
- Determine odour mitigation effectiveness over time
- Monitor emission compliance and conduct N-butanol screening

► ACCURACY

The SM100 is an olfactometer with an unprecedented accuracy:

- Selectable dilution range from 2 to 30,000 OU
- Meets EN13725 and ASTM E679 for olfactometer design
- Keep noses sensitive even in the harshest ambient odours
- Constant presentation air flow (not dependant on Sniff Rate)
- Odourless diluting air from compressed air tanks

► EASE-OF-USE

1. Wear the PTFE facemask and the portable compressed air tank.
2. Open the valve to purge nose with odourless air.
3. Slowly open the sliding valve to increase the concentration until the odour becomes detectable.
4. Read from the valve position indicator the sample strength (Dilution to threshold or OU).



► HOW IT WORKS

The SM100 draws a sample of ambient air via venturi pump and dilutes it using fresh odourless air from a compressed air tank. Operator uses an adjustable sliding valve to control the ratio of fresh to ambient air.

► COMPARISON TO FULL SCALE LAB'S

Sample	Lab Results (OU)	SM100C Results (OU)
1	116	94
2	108	164
3	139	131
4	201	219
5	1846	1441

*Comparative study between SM100 and EN13725 odour laboratory



► SCENTROID
431 Alden Road. #3
Markham, ON, L3R 3L4

► CONTACT US
Local: +1.416.479.0078
Toll-Free 1.888.988.IDES (4337)

Dystrybucja i serwis: ATUT Sp. z o.o.
ul. B. Prusa 8, 20-064 LUBLIN
tel./fax: 81 740 33 45
e-mail: info@atut.lublin.pl;
www.atut.lublin.pl

► FOLLOW US



RECYCLED PAPER

SPECIFICATIONS

SM100

Manufacturer	SCENTROID
Model	SM100
Air Supply Capacity	20 min per tank
# of samples per tank refill	15-20
Dilution range	2 – 30,000
Dilution Principle	Stainless Steel Eductor
Number of Dilution Steps	15 (adjustable range)
Selectable Ranges	2-30,000; 2-101; 4-678; 44-656; 2-3600; 2000-30,000
Pres. Flow Rate:(l/min)	20
Presentation Face Velocity (m/s)	0.3
Face Mask	Half-face PTFE
Wetted Material	Stainless Steel and PTFE
Tank material	Carbon Fibre
Dimensions (in)	16x6x6
Weight Kg/(lb)	3.5 (8)



UNPARALLELED RELIABILITY

The SM100 uses no electronic components and incorporates the highest grade of industrial components for the highest level of reliability. All parts have been tested to provide years of service with minimal maintenance. The SM100 is designed and built to last!

BENEFITS OF INFIELD OLFACTOMETER

- Lower capital and operational costs
- Elimination of sample degradation caused by sample shipment (time, temperature and pressure imposed during shipping).
- Use of local population as panellist

ZERO MAINTENANCE

Requires no other accessories such as sample bags. No contamination: PTFE nose masks and stainless steel wetted surfaces. No filters to change. No pumps or other moving parts to maintain. Does not require frequent re-calibration. An instrument you can rely on!



SCENTROID
431 Alden Road. #3
Markham, ON, L3R 3L4

CONTACT US
Local: +1.416.479.0078
Toll-Free 1.888.988.IDES (4337)

Dystrybucja i serwis: ATUT Sp. z o.o.
ul. B. Prusa 8, 20-064 LUBLIN
tel./fax: 81 740 33 45
e-mail: info@atut.lublin.pl;
www.atut.lublin.pl

FOLLOW US



RECYCLED PAPER