



Ambient Air Quality Monitoring

# Particulate Monitoring PM<sub>10</sub>, PM<sub>2.5</sub> and TSP Atut Sp. z o.o.

ul. B. Prusa 8, 20-064 Lublin tel./fax: 081 740 33 45 e-mail: info@atut.lublin.pl www.atut.lublin.pl

**A17** 

### Ambient Air Quality Monitoring

## Particulate Monitoring PM<sub>10</sub>, PM<sub>2.5</sub> and TSP

The particulate matter monitor SM200 can be used for both automatic measurement and filter sampling. The SM200 can be equipped with a  $PM_{10}$  head, a  $PM_{2.5}$  or a TSP head, designed for either 2.3 m³/h or 1.0 m³/h.

The SM200 is a cost-effective solution for particulate matter monitoring and sampling. It can be completely remote controlled and is ideally suited for use in modern monitoring stations.

The SM200 can generate both 24-hour data based on beta attenuation and real-time data based on particle counting. Due to the extensive automatic QA/QC procedures, the SM200 operates with high accuracy and precision.

The SM200 meets the new regulation for automatic monitoring of  $PM_{10}$  and  $PM_{2.5}$ . It also meets the new regulation for particulate matter sampling on filter membranes for further analysis of cadmium, nickel, PAH and other substances.

### MONITORING AND SAMPLING

The SM200 provides both automatic monitoring of particulate matter as well as sampling of air on filters. Standard 47 mm filters are used.

### INTERNATIONAL APPROVALS

- Approved by TÜV, MCERTS, U.S. EPA, and CNR among others.
- Reference sampler according to EN 12341, when equipped with 2.3 m³/h inlet head.

### **BETA ATTENUATION**

The SM200 is an automatic particulate monitor for monitoring of  $PM_{10}$  and  $PM_{2.5}$ . A filter is loaded into the filter magazine and a Geiger counter detects the beta attenuation before and after sampling. The measurement time of the instrument is 8-24 hours.

### **REAL-TIME PARTICLE MEASUREMENTS**

The SM200 can generate real-time data using particle counting. A laser diode based particle counting system is placed before the sampling filter.

The number as well as the size of the particles are measured. The real-time data is calibrated using the results from the beta attenuation measurements.

### **BUILT-IN CALIBRATION**

Span, linearity and zero calibrations are automatically controlled at regular intervals.

### TS200 - TEMPERATURE STABILIZED INLET TUBE

The TS200 is used for keeping the sample air at ambient temperature. Since the temperature of the sample is controlled, no factors have to be added to the measurement results. This means that the SM200 always provides accurate results, unaffected by both seasonal and geographical factors. The TS200 is available as an option and has to be ordered separately.

### QA/QC PROCEDURES

The 47 mm filters can be weighed according to gravimetric reference methods. The results can be used for quality control of the automatic measurements.

Extensive QA/QC procedures regulate the operation of the SM200 by use of internal sensors such as:

- External temperature
- External pressure
- Filter temperature
- Filter relative humidity
- Filter pressure drop
- Inlet flow rate
- Geiger temperature
- Geiger counts
- Geiger high voltage

### SERIAL COMMUNICATION – REMOTE CONTROL

The instrument is equipped with three RS232 serial ports that can be used for connecting the SM200 to a PC, modem or data logger. By using the serial ports, the SM200 can be remotely controlled, which means that data retrieval and other operations can be performed at distance. The SM200 is ideally suited for use in a monitoring network.

For further information, please visit www.opsis.se.



### SYSTEM OVERVIEW

SM200 analyser unit equipped with the TS200, which is used for keeping the sample air at ambient Inlet head temperature. (PM<sub>10</sub>, PM<sub>2.5</sub>, TSP) The TS200 includes an inlet tube, ventilation hose, drain hose, fan and flanges. Inlet tube Wall-mounted fan Drain Ventilation hose hose



PM<sub>10</sub> inlet head



Filters and filter holder



Extra filter containers minimize maintenance and make changing of filters easy

### **TECHNICAL SPECIFICATIONS**

Dimensions, sampling module Dimensions, pumping module Weight, sampling module Weight, pumping module Voltage supply Power consumption Display Keypad Data storage

Serial interface Analogue output Digital status output Degree of protection Operating temperature 630×440×300 mm<sup>(1)</sup> 310×280×250 mm<sup>(1)</sup>

25 kg 10 kg 230 V/50-60 Hz 800 W

LCD, 4 × 20 characters

Membrane 120 days

(based on 24 h sampling)

3×RS 232 0-10 V/0-20 mA Closing relay IP 20 +5°C-+40°C (+40°F-+100°F)

Performance

Operative flow rate Mass measurement range Detection limit Measurement time

16.67 I/min alt. 38.33 I/min

0-1500 µg/m<sup>3</sup>

0.5 µg/m3 (24 h average), 2.3 m3/h 8-24 h, beta attenuation 1 min-24 h, particle counting

**Radioactive Source Data** 

Source Total activity Half life Type

0.5 MBq (13 µCi) 5730 years Beta

### SM200 Includes as Standard

Analyser unit 230/115 V, 1.0 m³/h/2.3 m³/h

Pump module 230 V Beta source 2 filter containers 40 filter holders

2.5 m stainless steel inlet tube

Options (separately ordered) Inlet head PM<sub>10</sub> at 1.0 m<sup>3</sup>/h (M000501) Inlet head PM<sub>2.5</sub> at 1.0 m<sup>3</sup>/h (M000502) Inlet head PM<sub>2.5</sub> at 2.3 m³/h (M000512) Inlet head PM<sub>2.5</sub> at 2.3 m³/h (M000513)

Real-time particle measurements based on particle counting (RTPM) Analyser configured as sampler (SM200-SAMP)

Analyser configured as atmospheric stability monitor (SM200-STAB) Differential pressure measurements (M000990)

Analyser equipped with extra memory (E027146) TS 200, temperature stabilized inlet tube (TS200) I/O system for additional inputs and outputs (IOU020)

Pump module, 115 V (PL200-1) Ethernet connection (E084156)

### Accessories

Filter opener (A0974100) Consumables kit (M300505)

Teflon filters, 2.0 µm, 100 filters per box (M000900) Teflon filters, 1.0 µm, 100 filters per box (M000901) Cellulose filters, 1.0 µm, 100 filters per box (M000905) Glass fibre filter, 100 filters per box (M000920)

Extra filter container (M201680)

 $<sup>^{(1)}</sup>$  Length  $\times$  Width  $\times$  Height



### Particulate Monitoring by OPSIS

A cost-effective solution for particulate matter monitoring and sampling

Real-time measurements of PM<sub>10</sub> and PM<sub>2.5</sub> based on particle counting

Meets the new regulation for automatic monitoring of PM<sub>10</sub> and PM<sub>2.5</sub>

Calibration only once per year

Meets the new regulation for sampling on 47 mm filters for further analysis of cadmium, nickel, PAH and other substances

Samples at ambient temperature – no need for correction factors

Certified according to EN 15267

Approved by TÜV, U.S. EPA, and Chinese EPA, and others

A17

Please contact your OPSIS supplier to discuss your particular system requirements, including the compounds you wish to monitor. Separate product and other industrial application sheets are available.

Specifications subject to change without notice.

**OPSIS AB** 

Box 244, SE- 244 02 Furulund, Sweden +46 46 72 25 00 • info@opsis.se • www.opsis.se Atut Sp. z o.o.

ul. B. Prusa 8, 20-064 Lublin tel./fax: 081 740 33 45 e-mail: info@atut.lublin.pl www.atut.lublin.pl